


Nr.	Part nr.	Name
001	DA00000379	STARTER,REWIND ASSY
002	DA00000380	PULLEY
003	DA00000096	SCREW & WASHER ASS'Y
004	DA00000064	OIL SEAL
005	DA00000381	OIL SEAL
006	DA00000382	CRANKCASE1
007	DA00000383	CRANKCASE2
008	DA00000384	BALL BEARING
009	DA00000385	KNOCK
010	DA00000386	CRANKSHAFT COMPL
011	DA00000077	WOODRUFF KEY
012	DA00000387	PISTON
013	DA00000388	RING,PISTON
014	DA00000073	NEEDLE BEARING 8
015	DA00000389	PIN,PISTON
016	DA00000071	CLIP
017	DA00000390	GASKET,CRANKCASE
018	DA00000134	HEX. SOCKET HEAD BOLT M5X30
019	DA00000391	GASKET,CYLINDER
020	DA00000392	CYLINDER
022	DA00000080	SOCKET HEAD BOLT M5X20
023	DA00000393	FLYWHEEL COMPL
024	DA00000394	IGNITION COIL ASSY
025	DA00000395	INSULATOR,IGNITION COIL
026	DA00000396	SOCKET HAED BOLT M4
027	DA00000397	NUT,M6
028	DA00000398	WASHER
029	DA00000399	CLUTCH ASS'Y
030	DA00000400	WASHER
031	DA00000401	BOLT,CLUTCH
032	DA00000402	DRUM,CLUTCH COMPL
033	DA00000403	CLUTCH CASE
034	DA00000092	OUTER SNAP RING
035	DA00000405	BUFFER RUBBER
036	DA00000406	PIPE HOLDER
037	DA00000407	PIPE HOLDER
038	DA00000408	BUFFER RUBBER
039	DA00000409	BUFFER RUBBER
040	DA00000410	SOCKET HEAD BOLT M5X12(SW)
041	DA00000411	GASKET,INSULATOR
042	DA00000412	INSULATOR
043	DA00000413	WIRE COMPL
044	DA00000137	SOCKET HEAD BOLT M5X25
045	DA00000414	GASKET,CARBURETOR
046	DA00000415	INSULATOR,CARBURETOR
047	DA00000416	GASKET,CARBURETOR

Nr.	Part nr.	Name
049	DA00000418	GASKET,CARBURETOR
050	DA00000419	CHOCK LEVER
051	DA00000420	CLEANER PLATE
052	DA00000421	CHOCK PLATE
053	DA00000422	TAPPING SCREW 3X10
054	DA00000106	PLATE
055	DA00000107	PAN HEAD SCREW M5X63
056	DA00000198	SPRING WASHER
057	DA00000423	AIR FILTER
058	DA00000424	AIR CLEANER COVER
059	DA00000425	GASKET,MUFFLER
060	DA00000426	MUFFLER,EXHAUST
061	DA00000427	SOCKET HEAD BOLT M5X50(W)
062	DA00000428	FUEL TANK
063	DA00000122	FUEL TANK CAP COMPLETE
064	DA00000117	TUBE L
065	DA00000116	TUBE S
066	DA00000120	HOSE CLAMP
068	DA00000118	GROMMET
069	DA00000429	BUFFER RUBBER
070	DA00000430	BUFFER RUBBER
071	DA00000432	TAPPING SCREW 4X12
072	DA00000431	STAND
073	DA00000433	CYLINDER COVER
074	DA00000435	MUFFLER COVER
075	DA00000436	SHAFT
077	DA00000129	HANGER STOPPER
078	DA00000130	NUT M5
079	DA00000131	HANGER
080	DA00000437	PIPE,SHAFT COMPL
081	DA00000374	HANDLE HOLDER 3
082	DA00000438	HANDLE INSTALLATION BOARD
083	DA00000439	CONTROL LEVER ASSEMBLY
090	DA00000144	PROTECTOR CLAMP
092	DA00000142	CROSSRECESS BOLT M6X23
093	DA00000143	SOCKET HEAD BOLT M5X14 (W,SW)
095	DA00000146	SCREW ASSEMBLY M5X40
096	DA00000148	CUTTER
097	DA00000149	TAPPING SCREW, ST5X25
098	DA00000150	INNER SNAP RING
099	DA00000151	OUTER SNAP RING
100	DA00000152	BALL BEARING #609ZZ
102	DA00000154	OIL BOLT M6X8
103	DA00000155	GEAR CASE
104	DA00000156	GUARD
105	DA00000157	SCREW ASSEMBLY,M5X25

Nr.	Part nr.	Name
106	DA00000158	BALL BEARING 626ZZ
108	DA00000160	BALL BEARING 6000DDU
109	DA00000161	INNER SNAP RING
110	DA00000162	RECEIVE WASHER
111	DA00000163	CUTTER BODY
112	DA00000164	SPRING SEAT
113	DA00000165	SPRING
114	DA00000166	REEL
115	DA00000167	NYLON LINE
116	DA00000168	BODY CAP
118	DA00000170	WASHER CLAMP COMPL
119	DA00000171	SPRING WASHER
120	DA00000172	NUT
121	DA00000442	LABEL
122	DA00000443	LABEL,MODEL
123	DA00000445	LABEL,CAUTION
124	DA00000447	CRANKCASE ASS'Y
125	DA00000448	CRANKCASE 1 ASS'Y
126	DA00000449	CRANKCASE 2 ASS'Y
127	DA00000450	CLUTCH CASE COMPLETE
128	DA00000452	PLATE,AIR CLEANER ASSY
129	DA00000453	GEAR CASE ASSY
130	DA00000454	
153	DA00000459	HOLDER
154	DA00000460	LEVER CASE L
155	DA00000461	LOCK PIN
156	DA00000462	LEAF SPRING
157	DA00000463	SWITCHLEVER
158	DA00000464	SWITCH COVER
159	DA00000465	TAPPING SCREW PT3X16
160	DA00000466	TORSION SPRING
161	DA00000467	THROTTLE LEVER
162	DA00000468	TORSION SPRING
163	DA00000469	LOCK LEVER
164	DA00000470	CLAMP 24
165	DA00000471	LEAD UNIT
166	DA00000472	LEAD UNIT
167	DA00000473	CONTROL CABLE
168	DA00000474	CORRUGATE,TUBE
169	DA00000475	LEVER CASE R
170	DA00000476	TAPPING SCREW PT4X18
171	DA00000378	GEAR ASSEY
021-1	168648-5	
048-1	DA00000417	CARBURETOR
067-1	DA00000523	GASOLINE FILTER
091-1	DA00000525	PROTECTOR ASSY

<b>Nr.</b>	<b>Part nr.</b>	<b>Name</b>
094-1	DA00000526	PROTECTOR
137-1	DA00001139	SWIVEL
138-1	DA00001140	WASHER
139-1	DA00001141	SCREW
140-1	DA00001114	RING SPRING RETAINING
141-1	DA00001142	CABLE BRACKET
143-1	DA00001143	PUMP GASKET
144-1	DA00001144	PUMP DIAPHRAGM
145-1	DA00001145	PUMP BODY ASSEMBLY
146-1	DA00001146	INLET SCREEN
147-1	DA00001147	METERING DIAPHRAGM GASKET
148-1	DA00001148	METERING DIAPHRAGM ASSEMBLY
149-1	DA00001179	BODY ASSEMBLY,AIR PURGE
150-1	DA00001149	PRIMER PUMP
151-1	DA00001150	PRIMER PUMP COVER
152-1	DA00001151	SCREW




Nr.	Part nr.	Name
001	DA00000379	STARTER,REWIND ASSY
002	DA00000380	PULLEY
003	DA00000096	SCREW & WASHER ASS'Y
004	DA00000064	OIL SEAL
005	DA00000381	OIL SEAL
006	DA00000382	CRANKCASE1
007	DA00000383	CRANKCASE2
008	DA00000384	BALL BEARING
009	DA00000385	KNOCK
010	DA00000386	CRANKSHAFT COMPL
011	DA00000077	WOODRUFF KEY
012	DA00000387	PISTON
013	DA00000388	RING,PISTON
014	DA00000073	NEEDLE BEARING 8
015	DA00000389	PIN,PISTON
016	DA00000071	CLIP
017	DA00000390	GASKET,CRANKCASE
018	DA00000134	HEX. SOCKET HEAD BOLT M5X30
019	DA00000391	GASKET,CYLINDER
020	DA00000392	CYLINDER
022	DA00000080	SOCKET HEAD BOLT M5X20
023	DA00000393	FLYWHEEL COMPL
024	DA00000394	IGNITION COIL ASSY
025	DA00000395	INSULATOR,IGNITION COIL
026	DA00000396	SOCKET HAED BOLT M4
027	DA00000397	NUT,M6
028	DA00000398	WASHER
029	DA00000399	CLUTCH ASS'Y
030	DA00000400	WASHER
031	DA00000401	BOLT,CLUTCH
032	DA00000402	DRUM,CLUTCH COMPL
033	DA00000403	CLUTCH CASE
034	DA00000092	OUTER SNAP RING
035	DA00000405	BUFFER RUBBER
036	DA00000406	PIPE HOLDER
037	DA00000407	PIPE HOLDER
038	DA00000408	BUFFER RUBBER
039	DA00000409	BUFFER RUBBER
040	DA00000410	SOCKET HEAD BOLT M5X12(SW)
041	DA00000411	GASKET,INSULATOR
042	DA00000412	INSULATOR
043	DA00000413	WIRE COMPL
044	DA00000137	SOCKET HEAD BOLT M5X25
045	DA00000414	GASKET,CARBURETOR
046	DA00000415	INSULATOR,CARBURETOR
047	DA00000416	GASKET,CARBURETOR

Nr.	Part nr.	Name
049	DA00000418	GASKET,CARBURETOR
050	DA00000419	CHOCK LEVER
051	DA00000420	CLEANER PLATE
052	DA00000421	CHOCK PLATE
053	DA00000422	TAPPING SCREW 3X10
054	DA00000106	PLATE
055	DA00000107	PAN HEAD SCREW M5X63
056	DA00000198	SPRING WASHER
057	DA00000423	AIR FILTER
058	DA00000424	AIR CLEANER COVER
059	DA00000425	GASKET,MUFFLER
060	DA00000426	MUFFLER,EXHAUST
061	DA00000427	SOCKET HEAD BOLT M5X50(W)
062	DA00000428	FUEL TANK
063	DA00000122	FUEL TANK CAP COMPLETE
064	DA00000117	TUBE L
065	DA00000116	TUBE S
066	DA00000120	HOSE CLAMP
068	DA00000118	GROMMET
069	DA00000429	BUFFER RUBBER
070	DA00000430	BUFFER RUBBER
071	DA00000432	TAPPING SCREW 4X12
072	DA00000431	STAND
073	DA00000433	CYLINDER COVER
074	DA00000435	MUFFLER COVER
075	DA00000436	SHAFT
077	DA00000129	HANGER STOPPER
078	DA00000130	NUT M5
079	DA00000131	HANGER
080	DA00000437	PIPE,SHAFT COMPL
081	DA00000374	HANDLE HOLDER 3
082	DA00000438	HANDLE INSTALLATION BOARD
083	DA00000439	CONTROL LEVER ASSEMBLY
090	DA00000144	PROTECTOR CLAMP
092	DA00000142	CROSSRECESS BOLT M6X23
093	DA00000143	SOCKET HEAD BOLT M5X14 (W,SW)
095	DA00000146	SCREW ASSEMBLY M5X40
096	DA00000148	CUTTER
097	DA00000149	TAPPING SCREW, ST5X25
098	DA00000150	INNER SNAP RING
099	DA00000151	OUTER SNAP RING
100	DA00000152	BALL BEARING #609ZZ
102	DA00000154	OIL BOLT M6X8
103	DA00000155	GEAR CASE
104	DA00000156	GUARD
105	DA00000157	SCREW ASSEMBLY,M5X25



Nr.	Part nr.	Name
106	DA00000158	BALL BEARING 626ZZ
108	DA00000160	BALL BEARING 6000DDU
109	DA00000161	INNER SNAP RING
110	DA00000162	RECEIVE WASHER
111	DA00000163	CUTTER BODY
112	DA00000164	SPRING SEAT
113	DA00000165	SPRING
114	DA00000166	REEL
115	DA00000167	NYLON LINE
116	DA00000168	BODY CAP
118	DA00000170	WASHER CLAMP COMPL
119	DA00000171	SPRING WASHER
120	DA00000172	NUT
121	DA00000442	LABEL
122	DA00000443	LABEL,MODEL
123	DA00000445	LABEL,CAUTION
124	DA00000447	CRANKCASE ASS'Y
125	DA00000448	CRANKCASE 1 ASS'Y
126	DA00000449	CRANKCASE 2 ASS'Y
127	DA00000450	CLUTCH CASE COMPLETE
128	DA00000452	PLATE,AIR CLEANER ASSY
129	DA00000453	GEAR CASE ASSY
130	DA00000454	
153	DA00000459	HOLDER
154	DA00000460	LEVER CASE L
155	DA00000461	LOCK PIN
156	DA00000462	LEAF SPRING
157	DA00000463	SWITCHLEVER
158	DA00000464	SWITCH COVER
159	DA00000465	TAPPING SCREW PT3X16
160	DA00000466	TORSION SPRING
161	DA00000467	THROTTLE LEVER
162	DA00000468	TORSION SPRING
163	DA00000469	LOCK LEVER
164	DA00000470	CLAMP 24
165	DA00000471	LEAD UNIT
166	DA00000472	LEAD UNIT
167	DA00000473	CONTROL CABLE
168	DA00000474	CORRUGATE,TUBE
169	DA00000475	LEVER CASE R
170	DA00000476	TAPPING SCREW PT4X18
171	DA00000378	GEAR ASSEY
021-1	168648-5	
048-1	DA00000417	CARBURETOR
067-1	DA00000523	GASOLINE FILTER
091-1	DA00000525	PROTECTOR ASSY

<b>Nr.</b>	<b>Part nr.</b>	<b>Name</b>
094-1	DA00000526	PROTECTOR
137-1	DA00001139	SWIVEL
138-1	DA00001140	WASHER
139-1	DA00001141	SCREW
140-1	DA00001114	RING SPRING RETAINING
141-1	DA00001142	CABLE BRACKET
143-1	DA00001143	PUMP GASKET
144-1	DA00001144	PUMP DIAPHRAGM
145-1	DA00001145	PUMP BODY ASSEMBLY
146-1	DA00001146	INLET SCREEN
147-1	DA00001147	METERING DIAPHRAGM GASKET
148-1	DA00001148	METERING DIAPHRAGM ASSEMBLY
149-1	DA00001179	BODY ASSEMBLY,AIR PURGE
150-1	DA00001149	PRIMER PUMP
151-1	DA00001150	PRIMER PUMP COVER
152-1	DA00001151	SCREW




Nr.	Part nr.	Name
001	DA00000379	STARTER,REWIND ASSY
002	DA00000380	PULLEY
003	DA00000096	SCREW & WASHER ASS'Y
004	DA00000064	OIL SEAL
005	DA00000381	OIL SEAL
006	DA00000382	CRANKCASE1
007	DA00000383	CRANKCASE2
008	DA00000384	BALL BEARING
009	DA00000385	KNOCK
010	DA00000386	CRANKSHAFT COMPL
011	DA00000077	WOODRUFF KEY
012	DA00000387	PISTON
013	DA00000388	RING,PISTON
014	DA00000073	NEEDLE BEARING 8
015	DA00000389	PIN,PISTON
016	DA00000071	CLIP
017	DA00000390	GASKET,CRANKCASE
018	DA00000134	HEX. SOCKET HEAD BOLT M5X30
019	DA00000391	GASKET,CYLINDER
020	DA00000392	CYLINDER
022	DA00000080	SOCKET HEAD BOLT M5X20
023	DA00000393	FLYWHEEL COMPL
024	DA00000394	IGNITION COIL ASSY
025	DA00000395	INSULATOR,IGNITION COIL
026	DA00000396	SOCKET HAED BOLT M4
027	DA00000397	NUT,M6
028	DA00000398	WASHER
029	DA00000399	CLUTCH ASS'Y
030	DA00000400	WASHER
031	DA00000401	BOLT,CLUTCH
032	DA00000402	DRUM,CLUTCH COMPL
033	DA00000403	CLUTCH CASE
034	DA00000092	OUTER SNAP RING
035	DA00000405	BUFFER RUBBER
036	DA00000406	PIPE HOLDER
037	DA00000407	PIPE HOLDER
038	DA00000408	BUFFER RUBBER
039	DA00000409	BUFFER RUBBER
040	DA00000410	SOCKET HEAD BOLT M5X12(SW)
041	DA00000411	GASKET,INSULATOR
042	DA00000412	INSULATOR
043	DA00000413	WIRE COMPL
044	DA00000137	SOCKET HEAD BOLT M5X25
045	DA00000414	GASKET,CARBURETOR
046	DA00000415	INSULATOR,CARBURETOR
047	DA00000416	GASKET,CARBURETOR

Nr.	Part nr.	Name
049	DA00000418	GASKET,CARBURETOR
050	DA00000419	CHOCK LEVER
051	DA00000420	CLEANER PLATE
052	DA00000421	CHOCK PLATE
053	DA00000422	TAPPING SCREW 3X10
054	DA00000106	PLATE
055	DA00000107	PAN HEAD SCREW M5X63
056	DA00000198	SPRING WASHER
057	DA00000423	AIR FILTER
058	DA00000424	AIR CLEANER COVER
059	DA00000425	GASKET,MUFFLER
060	DA00000426	MUFFLER,EXHAUST
061	DA00000427	SOCKET HEAD BOLT M5X50(W)
062	DA00000428	FUEL TANK
063	DA00000122	FUEL TANK CAP COMPLETE
064	DA00000117	TUBE L
065	DA00000116	TUBE S
066	DA00000120	HOSE CLAMP
068	DA00000118	GROMMET
069	DA00000429	BUFFER RUBBER
070	DA00000430	BUFFER RUBBER
071	DA00000432	TAPPING SCREW 4X12
072	DA00000431	STAND
073	DA00000433	CYLINDER COVER
074	DA00000435	MUFFLER COVER
075	DA00000436	SHAFT
077	DA00000129	HANGER STOPPER
078	DA00000130	NUT M5
079	DA00000131	HANGER
080	DA00000437	PIPE,SHAFT COMPL
081	DA00000374	HANDLE HOLDER 3
082	DA00000438	HANDLE INSTALLATION BOARD
083	DA00000439	CONTROL LEVER ASSEMBLY
090	DA00000144	PROTECTOR CLAMP
092	DA00000142	CROSSRECESS BOLT M6X23
093	DA00000143	SOCKET HEAD BOLT M5X14 (W,SW)
095	DA00000146	SCREW ASSEMBLY M5X40
096	DA00000148	CUTTER
097	DA00000149	TAPPING SCREW, ST5X25
098	DA00000150	INNER SNAP RING
099	DA00000151	OUTER SNAP RING
100	DA00000152	BALL BEARING #609ZZ
102	DA00000154	OIL BOLT M6X8
103	DA00000155	GEAR CASE
104	DA00000156	GUARD
105	DA00000157	SCREW ASSEMBLY,M5X25

Nr.	Part nr.	Name
106	DA00000158	BALL BEARING 626ZZ
108	DA00000160	BALL BEARING 6000DDU
109	DA00000161	INNER SNAP RING
110	DA00000162	RECEIVE WASHER
111	DA00000163	CUTTER BODY
112	DA00000164	SPRING SEAT
113	DA00000165	SPRING
114	DA00000166	REEL
115	DA00000167	NYLON LINE
116	DA00000168	BODY CAP
118	DA00000170	WASHER CLAMP COMPL
119	DA00000171	SPRING WASHER
120	DA00000172	NUT
121	DA00000442	LABEL
122	DA00000443	LABEL,MODEL
123	DA00000445	LABEL,CAUTION
124	DA00000447	CRANKCASE ASS'Y
125	DA00000448	CRANKCASE 1 ASS'Y
126	DA00000449	CRANKCASE 2 ASS'Y
127	DA00000450	CLUTCH CASE COMPLETE
128	DA00000452	PLATE,AIR CLEANER ASSY
129	DA00000453	GEAR CASE ASSY
130	DA00000454	
153	DA00000459	HOLDER
154	DA00000460	LEVER CASE L
155	DA00000461	LOCK PIN
156	DA00000462	LEAF SPRING
157	DA00000463	SWITCHLEVER
158	DA00000464	SWITCH COVER
159	DA00000465	TAPPING SCREW PT3X16
160	DA00000466	TORSION SPRING
161	DA00000467	THROTTLE LEVER
162	DA00000468	TORSION SPRING
163	DA00000469	LOCK LEVER
164	DA00000470	CLAMP 24
165	DA00000471	LEAD UNIT
166	DA00000472	LEAD UNIT
167	DA00000473	CONTROL CABLE
168	DA00000474	CORRUGATE,TUBE
169	DA00000475	LEVER CASE R
170	DA00000476	TAPPING SCREW PT4X18
171	DA00000378	GEAR ASSEY
021-1	168648-5	
048-1	DA00000417	CARBURETOR
067-1	DA00000523	GASOLINE FILTER
091-1	DA00000525	PROTECTOR ASSY

<b>Nr.</b>	<b>Part nr.</b>	<b>Name</b>
094-1	DA00000526	PROTECTOR
137-1	DA00001139	SWIVEL
138-1	DA00001140	WASHER
139-1	DA00001141	SCREW
140-1	DA00001114	RING SPRING RETAINING
141-1	DA00001142	CABLE BRACKET
143-1	DA00001143	PUMP GASKET
144-1	DA00001144	PUMP DIAPHRAGM
145-1	DA00001145	PUMP BODY ASSEMBLY
146-1	DA00001146	INLET SCREEN
147-1	DA00001147	METERING DIAPHRAGM GASKET
148-1	DA00001148	METERING DIAPHRAGM ASSEMBLY
149-1	DA00001179	BODY ASSEMBLY,AIR PURGE
150-1	DA00001149	PRIMER PUMP
151-1	DA00001150	PRIMER PUMP COVER
152-1	DA00001151	SCREW





Nr.	Part nr.	Name
001	DA00000379	STARTER,REWIND ASSY
002	DA00000380	PULLEY
003	DA00000096	SCREW & WASHER ASS'Y
004	DA00000064	OIL SEAL
005	DA00000381	OIL SEAL
006	DA00000382	CRANKCASE1
007	DA00000383	CRANKCASE2
008	DA00000384	BALL BEARING
009	DA00000385	KNOCK
010	DA00000386	CRANKSHAFT COMPL
011	DA00000077	WOODRUFF KEY
012	DA00000387	PISTON
013	DA00000388	RING,PISTON
014	DA00000073	NEEDLE BEARING 8
015	DA00000389	PIN,PISTON
016	DA00000071	CLIP
017	DA00000390	GASKET,CRANKCASE
018	DA00000134	HEX. SOCKET HEAD BOLT M5X30
019	DA00000391	GASKET,CYLINDER
020	DA00000392	CYLINDER
022	DA00000080	SOCKET HEAD BOLT M5X20
023	DA00000393	FLYWHEEL COMPL
024	DA00000394	IGNITION COIL ASSY
025	DA00000395	INSULATOR,IGNITION COIL
026	DA00000396	SOCKET HAED BOLT M4
027	DA00000397	NUT,M6
028	DA00000398	WASHER
029	DA00000399	CLUTCH ASS'Y
030	DA00000400	WASHER
031	DA00000401	BOLT,CLUTCH
032	DA00000402	DRUM,CLUTCH COMPL
033	DA00000403	CLUTCH CASE
034	DA00000092	OUTER SNAP RING
035	DA00000405	BUFFER RUBBER
036	DA00000406	PIPE HOLDER
037	DA00000407	PIPE HOLDER
038	DA00000408	BUFFER RUBBER
039	DA00000409	BUFFER RUBBER
040	DA00000410	SOCKET HEAD BOLT M5X12(SW)
041	DA00000411	GASKET,INSULATOR
042	DA00000412	INSULATOR
043	DA00000413	WIRE COMPL
044	DA00000137	SOCKET HEAD BOLT M5X25
045	DA00000414	GASKET,CARBURETOR
046	DA00000415	INSULATOR,CARBURETOR
047	DA00000416	GASKET,CARBURETOR

Nr.	Part nr.	Name
049	DA00000418	GASKET,CARBURETOR
050	DA00000419	CHOCK LEVER
051	DA00000420	CLEANER PLATE
052	DA00000421	CHOCK PLATE
053	DA00000422	TAPPING SCREW 3X10
054	DA00000106	PLATE
055	DA00000107	PAN HEAD SCREW M5X63
056	DA00000198	SPRING WASHER
057	DA00000423	AIR FILTER
058	DA00000424	AIR CLEANER COVER
059	DA00000425	GASKET,MUFFLER
060	DA00000426	MUFFLER,EXHAUST
061	DA00000427	SOCKET HEAD BOLT M5X50(W)
062	DA00000428	FUEL TANK
063	DA00000122	FUEL TANK CAP COMPLETE
064	DA00000117	TUBE L
065	DA00000116	TUBE S
066	DA00000120	HOSE CLAMP
068	DA00000118	GROMMET
069	DA00000429	BUFFER RUBBER
070	DA00000430	BUFFER RUBBER
071	DA00000432	TAPPING SCREW 4X12
072	DA00000431	STAND
073	DA00000433	CYLINDER COVER
074	DA00000435	MUFFLER COVER
075	DA00000436	SHAFT
077	DA00000129	HANGER STOPPER
078	DA00000130	NUT M5
079	DA00000131	HANGER
080	DA00000437	PIPE,SHAFT COMPL
081	DA00000374	HANDLE HOLDER 3
082	DA00000438	HANDLE INSTALLATION BOARD
083	DA00000439	CONTROL LEVER ASSEMBLY
090	DA00000144	PROTECTOR CLAMP
092	DA00000142	CROSSRECESS BOLT M6X23
093	DA00000143	SOCKET HEAD BOLT M5X14 (W,SW)
095	DA00000146	SCREW ASSEMBLY M5X40
096	DA00000148	CUTTER
097	DA00000149	TAPPING SCREW, ST5X25
098	DA00000150	INNER SNAP RING
099	DA00000151	OUTER SNAP RING
100	DA00000152	BALL BEARING #609ZZ
102	DA00000154	OIL BOLT M6X8
103	DA00000155	GEAR CASE
104	DA00000156	GUARD
105	DA00000157	SCREW ASSEMBLY,M5X25

Nr.	Part nr.	Name
106	DA00000158	BALL BEARING 626ZZ
108	DA00000160	BALL BEARING 6000DDU
109	DA00000161	INNER SNAP RING
110	DA00000162	RECEIVE WASHER
111	DA00000163	CUTTER BODY
112	DA00000164	SPRING SEAT
113	DA00000165	SPRING
114	DA00000166	REEL
115	DA00000167	NYLON LINE
116	DA00000168	BODY CAP
118	DA00000170	WASHER CLAMP COMPL
119	DA00000171	SPRING WASHER
120	DA00000172	NUT
121	DA00000442	LABEL
122	DA00000443	LABEL,MODEL
123	DA00000445	LABEL,CAUTION
124	DA00000447	CRANKCASE ASS'Y
125	DA00000448	CRANKCASE 1 ASS'Y
126	DA00000449	CRANKCASE 2 ASS'Y
127	DA00000450	CLUTCH CASE COMPLETE
128	DA00000452	PLATE,AIR CLEANER ASSY
129	DA00000453	GEAR CASE ASSY
130	DA00000454	
153	DA00000459	HOLDER
154	DA00000460	LEVER CASE L
155	DA00000461	LOCK PIN
156	DA00000462	LEAF SPRING
157	DA00000463	SWITCHLEVER
158	DA00000464	SWITCH COVER
159	DA00000465	TAPPING SCREW PT3X16
160	DA00000466	TORSION SPRING
161	DA00000467	THROTTLE LEVER
162	DA00000468	TORSION SPRING
163	DA00000469	LOCK LEVER
164	DA00000470	CLAMP 24
165	DA00000471	LEAD UNIT
166	DA00000472	LEAD UNIT
167	DA00000473	CONTROL CABLE
168	DA00000474	CORRUGATE,TUBE
169	DA00000475	LEVER CASE R
170	DA00000476	TAPPING SCREW PT4X18
171	DA00000378	GEAR ASSEY
021-1	168648-5	
048-1	DA00000417	CARBURETOR
067-1	DA00000523	GASOLINE FILTER
091-1	DA00000525	PROTECTOR ASSY

<b>Nr.</b>	<b>Part nr.</b>	<b>Name</b>
094-1	DA00000526	PROTECTOR
137-1	DA00001139	SWIVEL
138-1	DA00001140	WASHER
139-1	DA00001141	SCREW
140-1	DA00001114	RING SPRING RETAINING
141-1	DA00001142	CABLE BRACKET
143-1	DA00001143	PUMP GASKET
144-1	DA00001144	PUMP DIAPHRAGM
145-1	DA00001145	PUMP BODY ASSEMBLY
146-1	DA00001146	INLET SCREEN
147-1	DA00001147	METERING DIAPHRAGM GASKET
148-1	DA00001148	METERING DIAPHRAGM ASSEMBLY
149-1	DA00001179	BODY ASSEMBLY,AIR PURGE
150-1	DA00001149	PRIMER PUMP
151-1	DA00001150	PRIMER PUMP COVER
152-1	DA00001151	SCREW