



Nr.	Part nr.	Name
008	122878-2	
009	346181-9	HANDGREEPBEUGEL (122878-2) P
010	266349-0	SQUARE BOLT M8X50 BHP441-454
011	451539-0	GRIPBASIS (122878-2) HR2300 P
013	141765-6	
014	233360-7	COMPRESSION SPRING 4 MT953
015	154935-8	HANDGREEP BDF454 P
016	142971-6	GEAR HOUSING COMPLETE
017	331890-3	BUS HR2300
018	211294-4	KOGELLAGER
019	232286-0	LEAF SPRING
020	346833-2	CHANGE PLATE B
021	346832-4	CHANGE PLATE A
022	213278-8	O RING 17 HR1830/2230/2460
023	455392-6	CHANGE LEVER
024	455394-2	CHANGE LEVER CAP
025	455391-8	CHANGE LEVER COVER
027	216019-1	STEEL BALL 3 TD020D/021D/090D
028	140266-1	BEITELHOUDER HR2601FT
029	332139-4	DRIVING FLANGE
030	227360-7	SPUR GEAR 51
033	234148-8	DRUKVEER 31MM HR2300
034	267153-0	SLUITRING 30 HR2300
035	257932-4	BORGRING SPIRO30 HR2300
036	267153-0	SLUITRING 30 HR2300
037	325783-4	BUS 9B HR2601
038	325791-5	SLAGSTUK "B" HR2611FT
039	325795-7	BLOKKEERING 10B HR2610
040	424267-0	STOOTRING 12 HR2300
041	325798-1	O-RING HUIS "A" HR2300
042	213073-6	O RING 9 HR2460-BHR202/261T
043	233979-2	VEERING 28 HR2300
044	325784-2	SLAGHAMER HR2300
045	213258-4	O RING 17.5
046	310345-1	ZUIGER-CILINDER HR2300
047	346036-8	GUIDE PLATE BHR261/261T
048	324215-8	PISTON JOINT HR2440
049	234098-7	COMPRESSION SPRING 14 BHR261T
050	210028-2	BALL BEARING 606ZZ UC3020A
051	257336-0	STOPRING EXT U6 BHR242
052	253186-1	FLAT WASHER 7 LF1000-BSS610
053	233360-7	COMPRESSION SPRING 4 MT953
054	346831-6	LOCK PLATE
055	326448-1	CAM SHAFT
056	227359-2	SPUR GEAR 10
057	332125-5	CLUTCH CAM

Nr.	Part nr.	Name
058	219014-0	BEARING 10 HR2432/2230/2460
059	257321-3	RING 8 MT870
060	310344-3	LAGERHUIS HR2300
061	211032-4	BALL BEARING 608ZZ 6412/6413
062	266437-3	INBUSBOUT M4X16
063	285735-6	LAGERBORGING HR2300
064	227719-8	TANDWIEL 26 HR2300
065	213728-3	O RING 68 BHR261/261T
069	141572-7	BINNENHUIS HR2300 A
070	213407-3	O RING 26 HR2230/4511C
071	213678-2	KEERRING 12MM HR3210FT A
072	262569-4	BUS 9 HR2300
073	211097-6	BALL BEARING 6000LLB
074	961006-2	RETAINING RING S-10 KP0810CK
075	240121-8	WAAIER 65 HR2300
076	515359-7	ANKER 240V HR2600
077	681652-2	INSULATION WASHER 6843/6844
078	210023-2	BALL BEARING 627DDW HR2230
079	267804-5	WAVE WASHER 15 HR2470
083	266361-0	TAPPING SCREW 4X30 9554NB
084	451527-7	TUSSENPLAAT HR2300
085	626634-7	VELD HR2600
086	451536-6	MOTORHUIS HR2600
087	850M38-1	HR2630T NAME PLATE
088	819390-8	BESCHERMLABEL HR2300 *
089	194074-2	CARBON BRUSH CB-325 GD0600
090	638655-7	KOOLBORSTELHOUDER HR2300
091	266556-5	MET.SCHROEF CK 3X12MM HR2300
092	266361-0	TAPPING SCREW 4X30 9554NB
093	850M42-0	HR2630T SERIAL NO. LABEL
094	819389-3	BESCHERMLABEL HR2300 *
095	682566-8	CORD GUARD 10 JS1300-TW0350
096	665890-4	NETSNOER 2X1.00 4.0MTR P
097	650625-6	SCHAKELAAR HR2300
099	687682-1	STRAIN RELIEF
100	266385-6	TAPPING SCREW 4X14 GA9020(S)
101	266326-2	TAPPING SCREW 4X18 HR2800/11FT
102	451528-5	HANDGREEPDEKSEL HR2300
103	266326-2	TAPPING SCREW 4X18 HR2800/11FT
104	194080-7	
105	286263-4	CAP 35 HR2440/2460/2470
106	233940-9	RING SPRING 19 HR2020/2432
107	418217-5	CHUCK COVER HR2450T-BHR261T
108	345333-9	STOPPER HR2450T-BHR261T
109	216022-2	STEEL BALL 7,0 HR1830/2432
110	345187-4	GUIDE WASHER HR2440/2460/2800

Nr.	Part nr.	Name
111	233916-6	CONICAL SPRING 21-29 HR1830
112	267279-8	FLAT WASHER 21 HR2811FT
113	324355-2	TOOL HOLDER HR2811FT
114	216013-3	STEEL BALL 6 LF1000
115	231669-1	TORSION SPRING 31 HR2450T
116	345334-7	CHANGE RING HR2450T
117	418218-3	CHANGE COVER HR2450T
118	216018-3	STEEL BALL 5,0 HR2811FT
119	345335-5	LEAF SPRING HR2811FT
120	267270-6	FLAT WASHER 24 HR2450T
121	233924-7	RING SPRING 21 HR2811FT
122	267447-3	SLUITRING 14 HR2300
123	234343-0	COMPRESSION SPRING 5
124	263005-3	RUBBER PIN 6 HR3200C/3210FCT