



Nr.	Part nr.	Name
001	188287-5	HANDLE SET 4350FCT
002	266048-4	TAPPING SCREW BIND 4X40 2107FK
003	266091-3	TAPPING SCREW BIND 4X50 HR1830
004	265995-6	TAPPING SCREW 4X18 JR3050-60T
005	442138-9	PACKING 4340CT-4341CT-4351FCT
006	214031-5	PLANE BEARING 4 BJV140/180
007	232207-2	LEAF SPRING BJV140/180
008	256117-9	PIN 4 4324
009	911111-5	SCREW M4X10 BJV140/180
010	911111-5	SCREW M4X10 BJV140/180
011	345240-6	LINEAR GUIDE 4340CT-4341CT
012	345240-6	LINEAR GUIDE 4340CT-4341CT
013	153338-3	GEAR HOUSING CPL 4340CT-4341CT
014	417839-8	SEAL PLATE 4340CT-4351FCT
015	231659-4	TORSION SPRING 6 BJV140
016	265026-1	SCREW M4 BJV140
017	419820-5	TOOL OPENER BJV140
018	421817-2	DUST COVER 4340CT-4351FCT
019	962068-3	RETAINING RING R-18 JR100FTK
020	135060-4	ROD ASSY 4350FCT
021	231660-9	TORSION SPRING 15 JR1000FTK
022	310136-0	BLADE HOLDER 4340CT-4351FCT
023	310135-2	PUSH PIN JR1000FTK-4030CT
024	665394-6	NETSNOER 2X1.00 2.5MTR P
025	682559-5	CORD GUARD 8 9554NB-JR1000FTK
026	687260-7	CORD CLAMP GA5021(C)
027	265995-6	TAPPING SCREW 4X18 JR3050-60T
028	645149-5	NOISE SUPPRESOR 4350FCT
029	266034-5	TAPSCHROEF CT4X16 A
030	324233-6	SAFETY WIRE 4340CT-4351FCT
031	631470-8	LED CIRCUIT 4351FCT
032	631766-7	CONTROLLER 4350FCT
033	650231-7	SWITCH 4350FCT
034	654532-5	TERMINAL BLOCK 5604R-4340FCT
035	188287-5	HANDLE SET 4350FCT
036	310134-4	SLIDER 4340CT-4341CT
037	961017-7	STOPRING E-3 HR2432/2470
038	961004-6	RETAINING RING S-8 BJV140/180
040	268090-1	PIN 4 4350FCT
041	265353-6	HEX SOCKET HEAD BOLT M4X12
042	153336-7	CRANK CPL 4340CT-4350FCT
043	313108-4	BALANCE PLATE 4340CT-4341CT
044	153335-9	GEAR CPL 4340CT-4351FCT
045	345235-9	PUSH PLATE 4340CT-4351FCT
046	253877-4	FLAT WASHER 8 BJV180
047	266050-7	TAPPING SCREW PT4X30 6827

Nr.	Part nr.	Name
048	961018-5	STOPRING E-5 BJV140/180
049	286032-3	CAP 5 BJV180
050	233139-6	COMPRESSION SPRING 3 BJV140
052	268063-4	PIN 4 4350FCT
053	153334-1	RETAINER CPL 4340CT-4341CT
054	252171-1	SQUARE NUT M5-8 4350FCT
055	421816-4	DUST SEAL 4341CT-4350FCT
056	153337-5	GEAR HOUSING CPL 4351FCT
057	210005-4	BALL BEARING 608DDW GA9010C
058	241881-5	FAN 52 4351FCT
059	266052-3	TAPPING SCREW FLANGE PT4X60
060	417838-0	BAFFLE PLATE 4340CT-4341CT
061	593508-6	FIELD ASSY 220-240V 4340CT
062	517398-3	ARMATURE ASSY 220-240V 4341CT
063	191962-4	CARBON BRUSH CB-419 JR1000FTK
064	643936-6	BRUSH HOLDER 4350FCT
066	863673-8	NAAMPLAAT 4350FCT
068	419886-5	MOTOR HOUSING 4350FCT
069	259039-2	SELF LOCK 6 4350FCT-9562CR
070	688117-5	MAGNET SLEEVE 9566PCV01-9562CR
071	267756-0	WAVE WASHER 6 9565PCV01
072	421494-0	RUBBER RING 19 DP4011
073	211021-9	KOGELLAGER 607LLB A
074	681636-0	INSULATION WASHER 6827-HR2432
075	232208-0	LEAF SPRING 4340FCT-4351FCT
076	922226-3	HSH BOLT M5X18 BJV140/180
077	345237-5	CRANK PLATE BJV140
078	317565-8	BASE CPL 4340CT-4351FCT
079	912107-9	KRUISKOPSCHROEF 4X8
080	345238-3	BASE PLATE 4340CT-4350FCT
039-1	212092-9	NEEDLE BEARING 407
051-1	272280-0	LEVER 17