



Nr.	Part nr.	Name
001	266326-2	TAPPING SCREW 4X18 HR2800/11FT
002	450071-1	TOP COVER BO4555K
003	266326-2	TAPPING SCREW 4X18 HR2800/11FT
004	645105-5	CONDENSATOR 0.1uF A
005	687124-5	STRAIN RELIEF MT953-HP1631
006	682569-2	CORD GUARD BO4555K/4556K/4565K
007	665383-1	NETSNOER 2X1.00 2.5MTR A
008	191962-4	CARBON BRUSH CB-419 JR1000FTK
009	643995-0	BRUSH HOLDER BO4555K
010	654532-5	TERMINAL BLOCK 5604R-4340FCT
011	651527-9	SWITCH BO4555K-BO5030/5031
012	424039-3	SWITCH COVER BO4565K
013	450072-9	MOTOR HOUSING BO4556K
014	867379-0	BO4558 NAME PLATE
015	593649-8	FIELD ASSY 240V BO4556K
016	266560-4	TAPPING SCREW 4X40 BO4558
018	681652-2	INSULATION WASHER 6843/6844
019	515708-8	ARMATURE ASSY 220-240V BO4556K
020	267806-1	WASHER 9 BO4556K
021	211092-6	BALL BEARING 629DDW 2107FK
022	450070-3	BEARING BOX BO4556K/4558
023	266326-2	TAPPING SCREW 4X18 HR2800/11FT
024	241671-6	FAN 63 BO4557K/4558
025	450069-8	FAN GUIDE BO4557K/4558
026	266026-4	TAPPING SCREW CT4X12 BO4558
027	162299-6	LEVER CPL BO4558
028	266326-2	TAPPING SCREW 4X18 HR2800/11FT
029	424023-8	SPONGE SLEEVE 9 BO4555K
030	213983-7	O RING 4 BO4556K
031	318151-8	FOOT BO4556K
032	213983-7	O RING 4 BO4556K
034	318543-1	BASE BO4558
035	211131-2	BALL BEARING 6001DDW BSS610
036	313175-9	BALANCER BO4558
037	912117-6	SCREW M4X12 BO4556K/4558
038	213513-4	O RING 39 BO4558
039	158324-9	PAD CPL BO4556K
040	911116-5	SCREW M4X12 BO4558
017-1	210062-2	BALL BEARING 607ZZ MT953
033-2	424684-4	SPONGE 7X87X3