



Nr.	Part nr.	Name
001	424043-2	CAP 6844
002	345841-0	STOPPER BASE 75 6844
003	140493-0	GUIDE BOX CPL BFR750
004	346269-5	GUARD BFR6843/6844/540/550
005	345837-1	LEVER 6843
006	233211-4	COMPRESSION SPRING 2 6836/6843
007	256451-7	PIN 6 6836/6843
008	450107-6	FEEDER BOX BFR750
009	257685-5	SLEEVE 5 BFR440/540/550/750
010	310062-3	STOPPER 6836/6843/6844
011	231636-6	TORSION SPRING 4 6836/6844
012	256158-5	PIN 3 6844
013	226344-2	SPUR GEAR 16 6836
014	158374-4	RATCHET ARM CPL 6843
015	233212-2	COMPRESSION SPRING 6 6836/6844
016	158378-6	BOX COVER CPL 6844
017	265995-6	TAPPING SCREW 4X18 JR3050-60T
018	162201-9	DUST COVER 6844
019	416518-5	WHEEL 6836
020	345838-9	PLATE BFR540/550/750
021	450111-5	STOPPER 6843
022	265177-0	SCREW M3X5 6843
023	257764-9	SLEEVE 4 6844
024	234032-7	COMPRESSION SPRING 23 6844
025	450114-9	CASING COVER 6843
026	158379-4	CASING 75 CPL 6844
027	310237-4	SHIFTER PIN 6843
028	450110-7	INSULATION SLEEVE 6843
029	318181-9	CLAMPER 6843-BFR540
030	417056-0	DIAL 42 6844-BFR540/750
031	213107-5	O RING 12 2704-BFR540
032	267201-5	FLAT WASHER 6 6843/6844
033	912117-6	SCREW M4X12 BO4556K/4558
034	216001-0	STEEL BALL 3,5 6836-BTP130/140
035	912117-6	SCREW M4X12 BO4556K/4558
036	265779-2	SCREW M4X28 6836-BFR440/750
037	195183-0	CASING 75 SET BFR750
041	188306-7	SCREW GUIDE SET BFR750
042	265995-6	TAPPING SCREW 4X18 JR3050-60T
043	187478-5	HANDGR.SET BFR550/750 (3 CON)A
044	850D69-6	DFR750 NAME PLATE
045	265995-6	TAPPING SCREW 4X18 JR3050-60T
046	421467-3	DUST COVER 6836/6843/6844
047	214173-5	PLANE BEARING 14 BFR440/750
048	213262-3	O RING 18 HR4011C/3210FCT
049	216001-0	STEEL BALL 3,5 6836-BTP130/140

Nr.	Part nr.	Name
050	324808-1	SPINDLE B 6843
052	421927-5	SLEEVE 20 BFR440/540/750
054	267331-2	FLAT WASHER 25 BFR540/550/750
055	267331-2	FLAT WASHER 25 BFR540/550/750
056	234017-3	COMPRESSION SPRING 25 6843
057	223169-5	CLUTCH CAM C BFS440/450
058	216008-6	STEEL BALL 4 6827-UC3520A
059	226670-9	HELICAL GEAR 48 BFS440
060	211034-0	KOGELLAGER 5703R NIEUW
061	165115-1	RUBBER SLEEVE 10 BFS440/450
062	214017-9	PLANE BEARING 5 BFR440/550/750
063	253811-4	FLAT WASHER 5 5008MG
064	154937-4	GEAR CPL 18-44 BFS440/450
065	214017-9	PLANE BEARING 5 BFR440/550/750
066	213055-8	O RING 10 BFR440/540/550/750
067	419304-3	F/R CHANGE LEVER BFR440/750
068	650670-1	SCHAKELAAR BFR540/50 (3 CONT.)
069	643860-3	AANSLUITUNIT BCL182D(3 CONT.)P
071	638426-2	YOKE UNIT BFR440/750
074	619216-2	ARMATURE BFR550/750
076	194427-5	CARBON BRUSH CB-440 BTD130/140
077	638433-5	BRUSH HOLDER CPL BFR440/750
078	263032-0	RUBBER PIN 4 BTD130/140-BFS440
079	419307-7	FRONT COVER BFR440/540/550/750
080	265995-6	TAPPING SCREW 4X18 JR3050-60T
082	188306-7	SCREW GUIDE SET BFR750
083	187478-5	HANDGR.SET BFR550/750 (3 CON)A
084	267332-0	FLAT WASHER 26 BFR440/540/750
088	265995-6	TAPPING SCREW 4X18 JR3050-60T
089	188310-6	GUIDE ATTACHMENT SET 6843
090	188310-6	GUIDE ATTACHMENT SET 6843
091	233567-5	TORSION SPRING 4 6843/6844
092	268188-4	PIN 2 6843/6844
093	310282-9	GUIDE 6843/6844